

# UNITEST®



® Instruction Manual Cat. No. 9061

## TELARIS® Fi/RCD-Analyzer



---

---

Contents .....	Page
1.0 Introduction / Scope of Supply .....	4
1.1 Model and Type Designation .....	4
1.2 Product description .....	4
2.0 Transport and Storage .....	5
3.0 Safety Measures .....	5
3.1 Appropriate Usage .....	7
4.0 Display / Operation Elements .....	7
5.0 Carrying out Measurements .....	8
5.1 Voltage Measurement .....	9
5.2 General Information about RCD Tests .....	10
5.2.1 Information regarding RCD testing .....	10
5.2.2 Starting of RCD Test without RCD tripping, Function Vc/RE .....	11
5.2.3 Starting RCD Test with RCD Tripping, Function tRCD/Vc .....	12
5.2.4 Starting RCD Test with “RCD Tripping, Function Auto” .....	14
5.2.5 Starting Automatic RCD Test with RCD Tripping .....	16
6.0 Storing Measurement Data .....	17
6.1 Infrared Interface, send Measurement Data .....	18
7.0 Deleting Stored Measurement Data / Display of All Memory Entries .....	18
8.0 Energy Management .....	19
9.0 Maintenance .....	19
9.1 Cleaning .....	19
10.0 Battery Replacement .....	19
11.0 Internal fuse .....	20
11.1 Indication in the display at defect fuse .....	20
12.0 Calibration Interval .....	20
12.0 Technical Data .....	21
24 month Warranty .....	26

## References marked on instrument or in instruction manual:

- ⚠ Warning of a potential danger, comply with instruction manual.
- ☞ Reference. Please use utmost attention.
- ⚠ Caution! Dangerous voltage. Danger of electrical shock.
- Continuous double or reinforced insulation complies with Category II.
- ⚠ Warning of potential danger caused by accumulators and batteries.
- CE Conformity symbol, the instrument complies with the valid directives. It complies with the EMC Directive (89/336/EEC), Standards EN 50081 and EN 50082-1 are fulfilled. It also complies with the Low Voltage Directive (73/23/EEC), Standard EN 61010-1 is fulfilled.
- ⚠ **The instruction manual contains information and references necessary for safe operation and maintenance of the instrument.** Prior to using the instrument (commissioning / assembly) the user is kindly requested to thoroughly read the instruction manual and comply with it in all sections.
- ⚠ Failure to read the instruction manual or to comply with the warnings and references contained herein can result in serious bodily injury or instrument damage.

## 1.0 Introduction / Scope of Supply

You have purchased a high quality measurement instrument of Ch. BEHA GmbH which will allow you to carry out measurement over a long time period. The company Ch. BEHA GmbH is a member of the world-wide operating BEHA Group with its head office in Glottertal/Schwarzwald which also houses our development centre. The BEHA Group is a leading organisation for Test Measurement Instruments.

## 1.1 Model and Type Designation

The identification label is located on the rear of the instrument. It contains the instrument serial number and product designation. When questions arise regarding the instrument, please always quote product designation and serial number.

## 1.2 Product description

The UNITEST TELARIS FI/RCD Analyzer allows the testing of trip times of standard RCDs and selective RCDs using various residual currents. Additionally, the ground resistance and contact voltage can be measured.

- Testing of trip times of standard RCDs and selective RCDs using various residual currents.
- Testing of conventional, selective and all-current sensitive RC protection switches
- Automatic RCD test (all RCD tests are carried out automatically)
- Nominal residual currents may be selected: 10, 30, 100, 300, 500, and 1000mA
- Automatic phase detection
- Various curve shapes: Sine, 1/2 wave rectified DC current, DC current
- Start of measurement at 0° or 180°
- Display of: trip time, trip current, contact voltage, ground resistance
- Result assessment, result evaluation
- Data memory for up to 100 measurement results
- Infrared interface (RS232) for easy data transfer
- Energy management with integrated auto power off function
- Large, easily readable display
- Built in compliance with EN 61557 Part 1 and 6, EN 61010-1, DIN VDE 0413 Part 1 and Part 6,

## Scope of Supply

- 1 pc UNITEST TELARIS FI/RCD-Analyzer
- 1 pc 3 pole test lead
- 1 pc Test lead with mains plug
- 1 pc Crocodile clamps
- 3 pc Test probe
- 1 pc Protective Holster
- 1 pc Carrying Case
- 6 pcs Battery 1.5V, type IEC LR6 (Size AA)
- 1 pc Instruction manual

## 2.0 Transport and Storage

Please keep the original packaging for later transport, e.g. for calibration. Any transport damage due to faulty packaging will be excluded from warranty claims.

In order to avoid instrument damage, we recommend that batteries are removed when not using the instrument over a certain period of time. However, should the instrument be contaminated by leaking battery cells, you are kindly requested to return it to the factory for cleaning and inspection.

Instruments must be stored in dry and closed areas. In the case of an instrument being transported in extreme temperatures, a recovery time of at least 2 hours is required prior to instrument operation.

## 3.0 Safety Measures

The UNITEST Telaris FI/RCD Analyzer has been designed and checked in accordance with the safety regulations for Electronic test and Measurement Instruments EN 61010 and IEC 61010, and left our factory in a safe and perfect condition.

⚠ The instruction manual contains information and references necessary for safe operation and maintenance of the instrument.

⚠ The respective accident prevention regulations established by the professional association for electrical systems and equipment must be strictly met at all times.

⚠ In order to avoid electrical shock, the valid safety and VDE regulations regarding excessive contact voltages must receive the utmost attention when working with voltages exceeding 120V (60V) DC or 50V (25V)rms AC. The values in brackets are valid for limited ranges (as for example medicine and agriculture).

⚠ Measurements in dangerous proximity of electrical installations are only to be executed when instructed by a responsible electrical specialist, and never alone.

⚠ If the operator's safety is no longer guaranteed, the instrument is to be put out of service and protected against use. The safety can no longer be guaranteed if the instrument (or leads):

- shows obvious damage
- does not carry out the desired measurements
- has been stored for too long under unfavourable conditions
- has been subjected to mechanical stress during transport.

⚠ Avoid any heating up of the instrument by direct sunlight to ensure perfect functioning and long instrument life.

⚠ Prior to usage, inspect the instrument and test leads for external damage. Prior to any operation, ensure that connecting leads used and instruments are in perfect condition.

⚠ The instrument may only be used within the operating ranges as specified in the technical data section.

## 3.1 Appropriate Usage

- ⚠ The instrument may only be used under those conditions and for those purposes for which it was built.
- ⚠ When modifying or changing the instrument, the operational safety is no longer guaranteed.
- ⚠ The opening of the instrument for fuse replacement, for example, may only be carried out by professionals. Prior to opening, the instrument has to be switched off and disconnected from any voltages.
- ⚠ Any maintenance and calibration tasks may only be carried out by our repair service staff.
- ⚠ The instrument may not be operated if the battery case is open.
- ⚠ If the instrument is subjected to an extremely high electro-magnetic field, its functioning ability may be impaired.

## 4.0 Display / Operation Elements

### Display


1. Attention, warning symbol
2. Symbol "Limit" (Limitvalue)
3. Excess (breech) of contact voltage limit
4. Socket error
5. Battery status indication
6. Unit display
7. Display for selective RCD
8. Phase position nominal residual current
9. Contact voltage limit
10. Current type
11. Selected nominal residual current
12. Nominal residual current - multiplication factor
13. Symbol for memory entry
14. Measurement data display
15. Symbol for ramp function
16. Temperature overload, overheating of the instrument
17. AC voltage, display of mains voltage

### Operation Elements


18. LCD
19. Key "VC/UL" to select contact voltage limit
20. Nominal residual current selection
21. PE contact electrode
22. Key "Start"
23. Key "Current Type"
24. Key "Phase Position" for nominal residual current
25. Key "Store"
26. Key "Send"
27. Key "Clear"
28. Battery case (instrument rear)
29. Infrared RS232 PC interface
30. Key - "Multiplication Factor" for nominal residual current
31. Function selection switch
32. Display key to select individual measurement results

## 5.0 Carrying out Measurements

**! ☺** FAT (Final Approval Test) measurements have to be carried out in compliance with the appropriate applicable standards.



English



# Voltage Measurement

## 5.1 Voltage Measurement

- ⚠ Prior to usage the test instrument and the test leads have to be tested for correct functioning.
- ⚠ Test leads and test probes may only be touched at the handles provided. The user must not touch the test probes.
- ⚠ The measurement connectors may not be connected to external voltages exceeding 300 V AC or DC to avoid any instrument damage.
- ☞ When changing the measurement function or parameter  $I_{\Delta N}$  and UL parameters, the TELA-RIS Fi/RCD-Analyzer automatically switches to the voltage measurement function.
  - ▶ Select measurement function using the function selection switch (31).
  - ▶ Connect test lead /mains connection lead to the UUT, as described in figure 1 or 2.
  - ▶ Read measurement data on the display.
- ☞ No data storing possible !




Fig. 1




Fig. 2

## 5.2 General Information about RCD Tests

The contact voltage  $U_B$  and the trip time  $t$  required by the RCD to disconnect the subsequent current circuit from the mains represent important measurement units for the assessment of an RCD.

For this reason, IEC 60364 prescribes that

- a) the maximum allowable value for the contact voltage (25V/50V) may not be exceeded within any system during tripping at nominal residual current.
- b) the RCD must trip within a time limit of 300ms.

The task of an residual current device (RCD) consists in switching off a system within a defined time period after an error prior the contact voltage reaches the permissible limit value of 25V / 50V.

The system testing should be started by carrying out a visual inspection, in particular of the protective earth connection.

1. Within the IT system, the protective earth conductor doesnot have to be connected with the PEN but with the protective earth connection.
2. The protective earth conductor must be connected to the PEN prior to the RCD within the TN system.
3. An insulation measurement as described in Section 5.2 must be performed. In particular it must be proved, that there is no connection between N and PE following the RCD.
4. Proof regarding the low impedance connection of equipotential bonding conductors in compliance with Section 5.4 must be available.

☞ Time-delayed residual current devices trip at nominal residual current within 130...500ms, for double nominal fault current within 60...200 ms. Such RCDs are implemented as main residual current protection devices (please refer to IEC 61008-1) and are marked with the symbol " S ".

☞ The contact voltage represents the voltage present during an insulation error between two simultaneously touchable components.

⚠ At a measuring circuit without probe, available voltages between PE and earth can influence the measurement.

⚠ Before using the N-conductor as probe check that all neutral points have low ohm resistance to the main neutral line. A available voltage of the N conductor to the earth can influence the measurement.

The measuring function uses the N-conductor as a probe. Check first the connection between the neutral point of the distribution system and earth before the test is started. A possible voltage between the N-conductor and earth may influence the measurements.

⚠ Leakage currents by preconnected loads can influence the measuring

⚠ Attached loads or operating supplies which contains capacitors or circulating machines can elongate the trip time.

⚠ Any test and measurement procedures in circuits equipped with residual current devices should only be performed after having consulted the operator terminals (data processing systems, material processing, motors, etc.).

☞ Prior to testing, we recommend all loads are switched off as they could falsify the measurement result.


☞ The protective earth must be free of external voltage for the RCD test. However if an extraneous voltage is present, the instrument only indicates the voltage  $V_C$  having been generated by the measurement. The measurement interruption caused by excess of  $UL$  by  $V_C$  is only generated by the actual voltage present between the neutral conductor (N) and the protective earth (PE).

# Starting of RCD Test

## 5.2.1 Information regarding RCD testing

The instrument TELARIS RCD Analyzer allows the measurement of trip times for standard RCDs and selective RCDs for different residual currents. Additionally, the ground resistance and the contact voltage can be measured without RCD tripping. The additional ramp function allows determination of the exact residual current and trip time. The instrument is equipped with an automatic RCD function to carry out fully automatic RCD tests.

- Table 1 and 2 informs about the type of current to be selected and about multiplication factors of nominal residual current. The multiplication factors may not be selected within all measurement functions and are in these cases disabled for the user.
- The nominal residual current selection also allows selection of selective RCDs (not possible for RCD TEST  $I\Delta/ta/UB$ ). When selecting the selective RCD, the symbol "S" (7) appears on the display.
- To carry out a complete socket test, the contact electrode PE (21) must be touched. If the symbol socket error (4) appears, a PE error is present.




- If the instrument is switched off using function selection switch or if the instrument automatically switches off due to the automatic power off function, the pre-set nominal residual current value is maintained. Parameters such as phase position ( $0^\circ, 180^\circ$ ), current type (AC, DC Plus, DC) and the nominal residual current multiplication factor are reset to the standard (default) values ( $0^\circ$ , AC, x1).

If many measurements are carried out interrupted only by short breaks, the built-in over-temperature protection of the RCD Analyzer might respond, and the thermometer symbol (15) appears on the display. Subsequent measurements can only be carried out, once the instrument has cooled down and the thermometer symbol has gone out, thus avoiding any instrument damage. Any tests at nominal residual currents 10mA / 30mA may be started even if the thermometer symbol is on, as these currents do not lead to a heating up of the instrument.



- If the RCD trips during testing, the socket error symbol (4) is displayed. This symbol is also displayed if the RCD is not in order and an incorrect tripping has been caused!




The "Attention Symbol" indicates that one measurement unit has exceeded a limit value. When calling up the measurement data using "Display" key (18), the "Limit" symbol (2) or "UB>UL" (3) appears for the respective measurement unit.

## 5.2.2 Starting of RCD Test without RCD tripping, Function UB/RE

The contact voltage UB and the ground resistance RE are measured during this test by applying a current amounting to 40 % of the nominal residual current. The contact voltage displayed is extrapolated to nominal residual current  $I_{\Delta N}$  or to double the nominal residual current  $I_{\Delta N}$  for selective RCDs.

- ▶ Connect test lead / mains connection cable to test instrument.
- ▶ Connect test lead / mains connection cable to the UUT, as described in figure 1 or 2.
- ▶ Select desired measurement function Vc/RE using function selection switch (31).
- ▶ Set nominal residual current selection (20) to desired nominal current (depending on RCD).
- ▶ Select Limitvalue via contact voltage using key "Vc/UL" (19).
- ▶ Touch contact electrode PE (21). Note display.
- ☞ If the symbol "Socket Error" (4) is displayed, a PE error is present.
- ▶ Press key "Start" (22).
- ☞ After successful test the display key (32) is used to switch between measurement result.



### Display at contact voltage



### Display at earth resistance

- ☞ Measurement results can be saved via pressing key "Store" (25).
- ☞ If the condition of a faulty socket is to be saved, first press key "Start" (22). Upon hearing the "Error Signal" press the key "Store" (25).
- ☞ If the RCD trip, the "Attention" symbol (1) and "Socket error" symbol (4) are displayed

# Starting of RCD Test



$I_{\Delta N}$ : **30** mA  $\sim$   $U_L$ : 50V

## Display at RCD has tripped

### A possible reason could be:

- incorrect selection of test current.
- a residual current is present within the net to be tested, causing the RCD to trip early because it sums up with the test currents.
- RCD faulty.

☞ The calculated contact voltage is displayed up to an voltage of 70 V

The measurement is interrupted if the contact voltage exceeds the set contact voltage limit. "Attention" (1) and "UB>UL" (3) appears on the display.



**UB>UL**

**63** V

$I_{\Delta N}$ : **30** mA  $\sim$   $U_L$ : 50V




**UB>UL**

$I_{\Delta N}$ : **30** mA  $\sim$   $U_L$ : 50V

## 5.2.3 Starting RCD Test with RCD Tripping, Function tRCD/UB

The contact voltage  $V_C$  is measured during a test, by applying a current amounting to 40 % of the nominal residual current. The contact voltage displayed is extrapolated to nominal residual current  $I_{\Delta N}$  or to double the nominal residual current  $I_{\Delta N}$  for selective RCDs.

☞ Upon the examination of RCDs a break of 30 sec is had between pre-test and preliminary test.



- Connect test lead / mains connection cable to test instrument.
- Connect test lead / mains connection cable to the UUT, as described in figure 1 or 2.
- Select desired measurement function tRCD/UB using function selection switch (31).
- Set nominal residual current selection (20) to desired nominal current (depending on RCD).
- Set phase position using key 0° / 180° (24).
- Set current type (23) and multiplication factor using key (30).



☞ The current types and multiplication factors to be selected at set nominal residual current are listed in tables 1 and 2.

- ▶ Select contact voltage using key "VC" (19).
- ▶ Touch contact electrode PE (21). Note display.


☞ If the symbol "Socket Error" (4) is displayed, a PE error or other socket error is present.

- ▶ Press key "Start" (22).

☞ After successful test the display key (32) is used to switch between measurement result tRCD and VC within the measurement value display.



☞ The measurement is interrupted if the contact voltage exceeds the set contact voltage limit. "Attention" (1) and "UB>UL" (3) appears on the display.




### Display at limit of contact voltage is exceeded

If the RCD does not trip within correct tolerance values (also refer to table 3), the "Attention" symbol (1) and "Limit" (2) are displayed besides measurement value tRCD.

A possible reason could be:

- incorrect selection of test current.
- a residual current is present within the net to be tested, causing the RCD to trip early because it sums up with the test currents.
- RCD faulty.

### Display at trip time >300 ms



☞ Measurement results may be saved pressing key Store (25).

# Starting of RCD Test

- ☞ If the condition of a faulty socket is to be saved, first press key "Start" (22). Upon hearing the "Error Signal" press the key "Store" (25).

## 5.2.4 Starting RCD Test with "RCD Tripping, Function Auto"

For this test, the trip current  $I_{\Delta}$  of the RCD is measured. The contact voltage  $VC$  is measured during the preliminary test at a current of 40%  $I_{\Delta}$ . The RCD test is resumed after the successful preliminary test at a residual current, rising in steps of 10 % from 40 %  $I_{\Delta}$  until maximum 140 %  $I_{\Delta}$ . The presently active residual current is indicated on the display and in the event of the RCD tripping the trip time of the RCD is measured. The contact voltage  $VC$  is evaluated for the trip current  $I_{\Delta}$ .

- ☞ The method of the rising test current is not necessarily binding in compliance with VDE, however represents a useful aid during trouble shooting.

- ⚠ Test and measurement instruments within networks being protected by RCDs should only be used after agreement with the final instrument user (DP systems, process technology, motors, etc.).



$U_B > U_L$

$I_{\Delta}$ :  $U_L$ : 50V

If the contact voltage  $VC$  already exceeds the preset contact voltage limit  $U_L$  during the preliminary test, the measurement is disabled and the "Attention" symbol (1) and "UB>UL" (3) is displayed.

- ▶ Connect test lead / mains connection cable to test instrument.
- ▶ Connect test lead / mains connection cable to the UUT, as described in figure 1 or 2.
- ▶ Select desired measurement function ( $I_{\Delta}$  /  $t_{RCD}/VC$ ) using function selection switch (31).
- ▶ Set nominal residual current selection (20) to desired nominal current (depending on RCD).



- ☞ No possibility to check selective RCDs.


- ▶ Set phase position using  $0^\circ/180^\circ$  key (24) and current type by means of key (23).
- ▶ Select contact voltage using key "VC/UL" (19).
- ▶ Touch contact electrode PE (21). Note display.

- ☞ If the symbol "Socket Error" (4) appears a PE error is present.

- ▶ Press key "Start" (22).


- ☞ After a successful test, it is possible to select between measurement results trip current  $I_{\Delta}$ , trip time  $t_{RCD}$ , and contact voltage  $VC$  in the display (14) using display key (18).








## Display contact voltage

- ☞ The measurement results may be saved by pressing key "Store" (25).
- ☞ If the condition of a faulty socket is to be saved, first press key "Start" (22). Upon hearing the "Error Signal", press key "Store" (25).
- ☞ If due to the ramp current the contact voltage is exceeded, the measurement is interrupted and the current is displayed at the level at which the excess occurred.




If trip time tRCD of RCD exceeds 300ms, the measurement value for an trip time is displayed as ">300ms". The "Attention" symbol (1) is displayed and for trip time display, the symbol for overload (2) appears.



To make sure that the RCD is tripping correctly, a standard test (tRCD/VC) has to be carried out. **Example:** A correctly functioning RCD has a trip time of ">300ms" at 50 % I<sub>ΔN</sub>, whereas the trip time smaller than 300ms. When performing standard test at I<sub>ΔN</sub>.

- ☞ If the RCD already trips at 50 % I<sub>ΔN</sub> or not at all at a residual current value higher than 100 % I<sub>ΔN</sub>, the RCD is faulty or the incorrect nominal residual current has been selected. The attention symbol (1) is displayed and the symbol for exceeding the limit (2) is indicated together with the trip current (tRCD) display




# Starting of RCD Test


## 5.2.5 Starting Automatic RCD Test with RCD Tripping

The TELARIS RCD Analyzer is equipped with a fully automatic RCD analysis. As a first step, during a preliminary test, the contact voltage  $VC$  is measured at a current of 40 %  $I_{\Delta N}$  and extrapolated to the nominal current. Thereafter, various AC residual currents are generated and both trip time and contact voltage are verified. The user must only make sure to switch on RCD after tripping between the individual test programs. Then, the RCD analysis is automatically continued.

- ▶ Connect test lead / mains connection cable to test instrument.
- ▶ Connect test lead / mains connection cable to the EUT, as described in figure 1 or 2.
- ▶ Select desired measurement function (Auto) using function selection switch (31).
- ▶ Set nominal residual current selection (20) to desired nominal current (depending on RCD).
- ▶ Select contact voltage using key "VC/UL" (19).
- ▶ Touch contact electrode PE (21). Note display.
- ☞ If the symbol "Socket Error" (4) appears a PE error is present.
- ▶ Press key "Start" (22).
- ☞ The measurement is interrupted if the contact voltage exceeds the pre-set contact voltage limit. The following symbols appear: "Attention (1), "UB>UL" (3) and "Err




After successful preliminary test the following is displayed (14):




<b>"Pr 1" equals</b>	0.5x $I_{\Delta N}$ 0°, RCD must not trip
<b>"Pr 2" equals</b>	0.5x $I_{\Delta N}$ 180°, RCD must not trip
<b>"Pr 3" equals</b>	1x $I_{\Delta N}$ 0°, RCD must trip within 300ms (S-Type 130 ... 500ms) (test-time 500ms)
<b>"Pr 4" equals</b>	1x $I_{\Delta N}$ 180°, RCD must trip within 300ms (S-Type 130 ... 500ms)
<b>"Pr 5" equals</b>	2x $I_{\Delta N}$ 0°, RCD must trip within 150ms (S-Type 60 200ms)
<b>"Pr 6" equals</b>	2x $I_{\Delta N}$ 180°, RCD must trip within 150ms (S-Type 60 ... 200ms)
<b>"*Pr 7" equals</b>	5x $I_{\Delta N}$ 0°, RCD must trip within 40ms (S-Type 50 ... 150ms)
<b>"*Pr 8" equals</b>	5x $I_{\Delta N}$ 180°, RCD must trip within 40ms (S-Type 50 ... 150ms)

\*function not to be executed at 500mA and 1000mA RCDs

The RCD trips several times during measurement and has to be switched on again. Thereafter, the measurement is automatically continued and ends with the display "POS" or "Err" on the display (18).



Display at functioning RCD



Display at faulty RCD

"POS" is an abbreviation of positive and signifies that the RCD is functioning correctly. If "Err" (Error) is displayed, the measurement is immediately interrupted. "Err" indicates a defective RCD or that the contact voltage has been exceeded. The nominal residual current multiplication factor (12) together with the phase position of nominal residual current (9) indicates in which program the automatic test has been interrupted.

The measurement results may be stored by pressing key Store (25). It is advised to store when using this range, as the Report Studio Software enables a detailed decoding of the measurement results.

- ☞ To interrupt the function AUTO, change the measurement range using the selection switch (31)

- ☞ Possibility to save.

## 6.0 Storing Measurement Data

After successful measurement, it is possible to save measurement value by means of "Store" key (25). Altogether, approximately 100 measurement values can be saved. Proceed as follows:

- ▶ Carry out measurement.
- ▶ Store measurement result by pressing "Store" key (25).
- ▶ After successful storing a short signal is audible and the symbol "M" (13) is displayed, also, the memory address number briefly appears.
- ☞ In the event of pressing the Store-key when the memory is full, the "M" Symbol blinks briefly and an error signal is heard
- ☞ The data in the memory is maintained if instrument is switched off or during battery replacement.
- ☞ Double storing of a measurement is impossible !
- ☞ **Under certain, unintentional circumstances data may be lost or modified during electronic saving. CH. BEHA will not be held liable for financial and other loss being caused by data loss, wrong handling or any other reason.**
- ☞ **We recommend you to save and transmit the measurement results daily to your computer. In case of incidental outer influences you can lose saved measurement of the instrument.**

## 6.1 Infrared Interface, send Measurement Data

Additionally, all memorised measurement data may be transferred to the PC (data archive) by means of an Infrared Interface. For this purpose, the interface adapter and the Software "Report-Studio" (Cat. No. 1206) and Interface (Cat. No. 1157), available as an optional feature, are required.

The data transfer procedure is fairly easy:

- ▶ Apply the Interface adapter to TELARIS
- ▶ Connect adapter cable to PC (COM 2) via 9pole D-sub plug (RS232).
- ▶ Call the "Report-Studio" Software (please refer to user manual "Report-Studio").
- ▶ Select menu item "read data" or select the button "read data from measurement instrument" by mouse click. The message "send data" appears.
- ▶ Press key "Send" (26).
- ☞ Data transfer is carried out. After a few seconds all stored data is available for further processing in the PC.
- ☞ For further details, please refer to user manual "Report-Studio".

## 7.0 Deleting Stored Measurement Data / Display of All Memory Entries

It is possible to delete data by using key „Clear“ (27). Furthermore, it is possible to display the total number of measurement value entries on the display:

### Display of Total Number of Measurement Value Entries:

- ▶ Set measurement range selection switch (31) to one of the 5 measurements ranges.
- ▶ Briefly press „Clear“ key (27). A short beep signal is audible.
- ▶ The total number of all measurement values that have been saved is now displayed.

### Delete Last Stored Measurement Value:

- ▶ Set measurement range selection switch (31) to one of the 5 measurement ranges.
- ▶ Briefly press „Clear“ key (27). A short beep signal is audible and the number of the memorised measurement data is displayed. The total number of all stored measurement data is displayed. The display disappears after approximately 2 seconds.
- ▶ Now release the key „Clear“ (27) to avoid deletion of all memory entries.

☞ Deleting the last measurement value can be repeated as often as required, as long as data is available within the memory.

### Deleting all Stored Measurement Values:

- ▶ Set measurement range selection switch (31) to one of the 5 measurement ranges.
- ▶ Press „Clear“ key (27) for approx. 5 seconds.
- ▶ A beep signals are audible. The number of all stored measurement values is displayed.
- ▶ The last stored value is deleted after 2 seconds. After 5 seconds, all values are deleted.
- ▶ „0“ appears on the display. The memory is completely deleted, the „M“ symbol in the display disappears.

## 8.0 Energy Management

Approximately 5 minutes after last key operation, the instrument switches off automatically (auto-power-off). To switch the instrument on again, turn rotary switch from the „OFF“ position to the desired function.

If the batteries are almost completely discharged, the battery symbol (5) appears. The instrument continues functioning without necessarily respecting the specifications.

If the batteries continue to be used and discharged, the instrument switches off at a point when the minimum battery voltage level is reached and may not be switched on again.

## 9.0 Maintenance

When using the instrument in compliance with the instruction manual, no special maintenance is required.

### 9.1 Cleaning

If the instrument is dirty after daily usage, it is advised to clean it by using a damp cloth and a mild household detergent.

⚠ Prior to cleaning, ensure that the instrument is switched off and disconnected from external voltage supply and any other instruments connected (such as EUT, control instruments, etc.).

⚠ Never use acid detergents or dissolvents for cleaning.

## 10.0 Battery Replacement

If the battery symbol  appears in the display, proceed with battery replacement.



⚠ Prior to battery replacement remove the instrument from all measurement circuits.

⚠ The right order of the batteries is shown on the inside of the battery compartment.

⚠ Batteries with reversed polarity can lead to instrument destruction. Furthermore, they may explode or ignite.

⚠ Only use batteries as described in the technical data section type 6LR61.

- ▶ Switch off the instrument.
- ▶ Loosen screws on the instrument rear.
- ▶ Remove battery case cover (by slightly knocking the instrument in the palm of the hand).
- ▶ Remove discharged battery.
- ▶ Insert new battery by respecting the correct polarity.
- ▶ Replace battery case cover and tighten screws.
- ▶ Instrument is operational.



- ⚠ Never try to disassemble a battery cell. Never throw a battery into open flames as this could lead to an explosion. Never subject batteries to humidity.
- ⚠ Please consider your environment when disposing of used batteries. They belong in a rubbish dump for hazardous waste. Generally speaking you may return your batteries to the point of sale.
- ⚠ The appropriate regulations concerning return, recycling and disposal of used batteries must be respected at all times.
- ⚠ If the instrument is not used over an extended time period, we recommend to remove the battery. In the event of instrument contamination caused by leaking battery cells, the instrument has to be returned for cleaning and verification to our factory.

## 11.0 Internal fuse

The internal fuse protects the instrument from overload or wrong operation/use. The fuses can trigger, if tensions  $> 600 \text{ V AC/DC}$  are connected to the instrument.

- ⚠ The fuse is inside the instrument, the instrument must be opened for the exchange.
- ⚠ The fuses can only be replaced by returning the instrument to the factory or to an authorized sales repair service.
- ⚠ Exclusively use fuse of voltage, current and breaking capacity values in compliance with the technical data section.

### 11.1 Indication in the display at defect fuse

- ⚠ If the instrument is correctly connected to the mains and before the measurement displays the symbols attention (1) and UB > UL (3), the internal fuse has blown.

The fuse must be replaced and the measurement instrument then checked by returning the instrument to the factory or to an authorized sales repair service.

## 12.0 Calibration Interval

To obtain the specified measurement result accuracy the instrument should be regularly calibrated by our after sales service. We recommend a calibration interval of one year.

### 13.0 Technical Data

#### 13.1 Tables with test currents

**Table 1 Test Currents Function VC/RE, tRCD/VC, Auto (mA)**

$I_{\Delta N}$	UB/RE-Measurement:	x0.5			x1			x2			x5		
	Prestest												
10	4	5	3,5	5	10	14	10	20	28	20	50	70	50
30	12	15	10,5	15	30	42	30	60	84	60	150	212	150
100	40	50	35	50	100	141	100	200	283	200	500	707	500
300	120	150	105	150	300	424	300	600	849	600	1500		
500	200	250	175	250	500	707	500	1000					
1000	400	500			1000			2000					

**Table 2 Ramp Currents Function  $I_{<}$ , tRCD/VC (mA)**

$I_{\Delta N}$			
10	4-14	1,4-20	1-14
30	12-42	4,2 - 59	3-42
100	40-140	14-198	10-140
300	120-420	42-594	30-420
500	200-700	71-990	
1000	400-1400		

**Table 3 RCD Trip Times for standard RCB's**

Fi/RCD-Type $I_{\Delta N}$	Current Type	Current Type $I_{\Delta N}$	Test Current $I_{\Delta N}$	prescribed Trip Time	Test Time	Standard DIN VDE	Fi/RCD Analyzer
10mA/ 30mA/ 100mA/ 300mA/ 500mA/ 1000mA		x0.5	0.5x	-	2000ms, $I_{\Delta N} \geq 100mA$ : 500ms	IEC61008-1	✓
		x1	1x	<300ms	500ms	IEC61008-1	✓
		x2	2x	<150ms	150ms	IEC61008-1	✓
		x5	5x	<40ms	40ms	IEC61008-1	✓
		Ramp	0.4x- 1.4x	<300ms	300ms	IEC61008-1	✓
		x0.5	0.35x	-	2000ms, $I_{\Delta N} \geq 100mA$ : 500ms	IEC61008-1	✓
		x1	1.4x	<300ms	500ms	IEC61008-1	✓
		x2	2.8x	<150ms	150ms	IEC61008-1	✓
		x5	7x	<40ms	40ms	IEC61008-1	✓
		Ramp	0.1x- 1.4x	<300ms	300ms	IEC61008-1	✓
		x0.5	0.5x	-	2000ms, $I_{\Delta N} \geq 100mA$ : 500ms	0664- Part 100	✓
		x1	1x	<300ms	500ms	0664- Part 100	✓
		x2	2x	<150ms	150ms	0664- Part 100	✓
		x5	5x	<40ms	40ms	0664- Part 100	✓
		Ramp	0.1x- 1.4x	<300ms	300ms	0664- Part 100	✓

## Technical Data

**Table 4 Trip times for selective RCB's**

Fi/RCD-Type $I\Delta N$	Current Type	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	Fi/RCD Analyzer
100mA/ 300mA/ 500mA/ 1000mA	$\sim$	x0.5	0.5x	-	500ms	IEC61008-1	✓
		x1	1x	130...500ms	500ms	IEC61008-1	✓
		x2	2x	60...200ms	200ms	IEC61008-1	✓
		x5	5x	50...150ms	150ms	IEC61008-1	✓
	$\sim\sim$	x0.5	0.35x	-	500ms	IEC61008-1	✓
		x1	1.4x	130...500ms	500ms	IEC61008-1	✓
		x2	2.8x	60...200ms	200ms	IEC61008-1	✓
		x5	7x	50...150ms	150ms	IEC61008-1	✓
	$---$	x0.5	0.5x	-	500ms	0664- Teil100	✓
		x1	1x	130...500ms	500ms	0664- Teil100	✓
		x2	2x	60...200ms	200ms	0664- Teil100	✓
		x5	5x	50...150ms	150ms	0664- Teil100	✓

**Table 5 Trip times for RCB's with over current protection**

Fi/RCD-Type $I\Delta N$	Current Type	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	Fi/RCD Analyzer
10mA/ 30mA/ 100mA/ 300mA/ 500mA/ 1000mA	$\sim$	x0.5	0.5x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms	IEC61009-1	✓
		x1	1x	<300ms	500ms	IEC61009-1	✓
		x2	2x	<150ms	150ms	IEC61009-1	✓
		x5	5x	<40ms	40ms	IEC61009-1	✓
		Ramp	0.4x- 1.4x	<300ms	200ms	IEC61009-1	✓
	$\sim\sim$	x0.5	0.35x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms	IEC61009-1	✓
		x1	1.4x	<300ms	500ms	IEC61009-1	✓
		x2	2.8x	<150ms	150ms	IEC61009-1	✓
		x5	7x	<40ms	40ms	IEC61009-1	✓
		Ramp	0.1x- 1.4x	<300ms	200ms	IEC61009-1	✓
	$---$	x0.5	0.5x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms		✓
		x1	1x	<300ms	500ms		✓
		x2	2x	<150ms	150ms		✓
		x5	5x	<40ms	40ms		✓
		Ramp	0.1x- 1.4x	<300ms	200ms		✓

**Table 6 Trip times for selective RCB's with over current protection**

F/RCD-Type $I\Delta N$	Current Type	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	F/RCD Analyzer
(RCBO) (100mA/ 300mA/ 500mA/ 1000mA)	$\sim$	x0.5	0.5x	-	500ms	IEC61009-1	✓
		x1	1x	130...500ms	500ms	IEC61009-1	✓
		x2	2x	60...200ms	200ms	IEC61009-1	✓
		x5	5x	50...150ms	150ms	IEC61009-1	✓
	$\sim\sim$	x0.5	0.35x	-	500ms	IEC61009-1	✓
		x1	1.4x	130...500ms	500ms	IEC61009-1	✓
		x2	2.8x	60...200ms	200ms	IEC61009-1	✓
		x5	7x	50...150ms	150ms	IEC61009-1	✓
	$---$	x0.5	0.5x	-	500ms		✓
		x1	1x	130...500ms	500ms		✓
		x2	2x	60...200ms	200ms		✓
		x5	5x	50...150ms	150ms		✓

**Table 7 Trip times for impulse resistant RCB's**

F/RCD-Type	Current Type	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	F/RCD Analyzer
10mA/ 30mA/ 100mA/ 300mA/ 500mA/ 1000mA	$\sim$	x0.5	0.5x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms	IEC61008-1	✓
		x1	1x	10...300ms	500ms	IEC61008-1	✓
		x2	2x	10...150ms	150ms	IEC61008-1	✓
		x5	5x	10...40ms	40ms	IEC61008-1	✓
		Ramp	0.4x- 1.4x	10...200ms	200ms	IEC61008-1	✓
		x0.5	0.35x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms	IEC61008-1	✓
	$\sim\sim$	x1	1.4x	10...300ms	500ms	IEC61008-1	✓
		x2	2.8x	10...150ms	150ms	IEC61008-1	✓
		x5	7x	10...40ms	40ms	IEC61008-1	✓
		Ramp	0.1x- 1.4x	10...300ms	200ms	IEC61008-1	✓
	$---$	x0.5	0.5x	-	2000ms, $I\Delta N \geq 100mA$ : 500ms		✓
		x1	1x	10...300ms	500ms		✓
		x2	2x	10...150ms	150ms		✓
		x5	5x	10...40ms	40ms		✓
		Ramp	0.1x- 1.4x	10...300ms	200ms		✓

# Technical Data

**Table 8**

Fi/RCD-Type $I\Delta N$	Current Type $I\Delta N$	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	Fi/RCD Analyzer
10mA/ 30mA	$\sim$	x0.5	0.5x $I\Delta N$	-	2000ms	VDE 661	set to 0.5x $I\Delta N$ , ✓
		x1	1x $I\Delta N$	<200ms	500ms	VDE 661	✓
		x5	5x $I\Delta N$	<40ms	40ms	VDE 661	✓
	$\sim\sim$	x0.5	0.35x $I\Delta N$	-	2000ms	VDE 661	set to 0.5x $I\Delta N$ , ✓
		x1	1.4x $I\Delta N$	<200ms	500ms	VDE 661	✓
		x5	7x $I\Delta N$	<40ms	40ms	VDE 661	✓
	$---$	x0.5	0.5x $I\Delta N$	-	2000ms		set to 0.5x $I\Delta N$ , ✓
		x1	1x $I\Delta N$	<200ms	2000ms		✓
		x5	5x $I\Delta N$	<40ms	40ms		✓

**Table 9**

Fi/RCD-Type	Current Type	Current Type $I\Delta N$	Test Current $I\Delta N$	prescribed Trip Time	Test Time	Standard	Fi/RCD Analyzer
fixed (SRCD) (10mA/ 30mA)	$\sim$	x0.5	0.5x $I\Delta N$	-	2000ms	VDE 662	set to 0.5x $I\Delta N$ , -
		x1	1x $I\Delta N$	<200ms	500ms	VDE 662	-
		x5	5x $I\Delta N$	<40ms	40ms	VDE 662	-
	$\sim\sim$	x0.5	0.35x $I\Delta N$	-	2000ms	VDE 662	set to 0.5x $I\Delta N$ , -
		x1	1.4x $I\Delta N$	<200ms	500ms	VDE 662	-
		x5	7x $I\Delta N$	<40ms	40ms	VDE 662	-
	$---$	x0.5	0.5x $I\Delta N$	-	2000ms		set to 0.5x $I\Delta N$ , -
		x1	1x $I\Delta N$	<200ms	500ms		-
		x5	5x $I\Delta N$	<40ms	40ms		-

Standardprüfung

## General Technical Data

Display	3 1/2 digit LCD
Mains nominal voltage	230V/240V +10% -15%
Mains nominal frequency	50/60Hz +/- 10%
Reference-Range:	+17°C to 27°C, max. 70% rel. humidity
Temperature-Range:	0°C to 40°C
Relative humidity:	max. 80%
Height above MSL:	up to 2000m
Battery type	6 mignon 1.5V, Type AA, IEC LR6 (no storage batteries)
Current consumption	approx. 15mA
Battery life at average usage	approx. 2 years
Auto power off	after approx. 5 min.
Built in fuse	M 1,0A/250V, 5x20 mm
Data memory	approx. 100 measurements
IR/RS232 interface	9600 Baud, 1 start bit, 8 data bits, even parity, 1 stop bit
Degree of contamination	2
Protection	2, protective insulation, IP50
Overvoltage class	CAT II / 300V
Dimensions (LxWxH)	235 x 105 x 70mm
Weight	650g (batteries included)

**Measuring Contact Voltage (UB)**

Measurement conditions ..... 40%  $I_{\Delta N}$   
 Measurement time ..... max 2000 ms, when exceeding limits, immediate cut-off  
 Measurement range ..... 0,6 ... 70,0 V bei  $I_{\Delta N}$  100, 300, 500, 1000mA  
 ..... 1...70 V bei  $I_{\Delta N}$  10, 30mA  
 Resolution ..... 0,1 V at  $I_{\Delta N}$  100, 300, 500, 1000mA  
 Tolerance ..... -0%...+10% /+6 Digit  
 Limits ..... 5V / 50V, contact voltage limit UL to be pre-selected

**Measuring Ground Resistance (RE)**

Measurement conditions ..... 40%  $I_{\Delta N}$   
 Measurement time ..... max. 2000 ms, when exceeding limits, immediate cut-off  
 Range: ..... 1...1999  $\Omega$  (at  $I_{\Delta N}$  100, 300, 500, 1000 mA)  
 ..... 0,01...1,99  $\Omega$  (at  $I_{\Delta N}$  10, 30 mA)  
 Resolution: ..... 1  $\Omega$  (at  $I_{\Delta N}$  100, 300, 500, 1000 mA)  
 ..... 0,01 k $\Omega$  (at  $I_{\Delta N}$  10, 30 mA)  
 Tolerance: .....  $\pm 10\%$  /  $\pm 10$  Digit (at  $I_{\Delta N}$  100, 300, 500, 1000 mA)  
 .....  $\pm 10\%$  /  $\pm 20$  Digit (at  $I_{\Delta N}$  10, 30 mA) depends of contact voltage

**Measuring Trip Time tA:**

Measurement range .....  $I_{\Delta N}$  10, 30, 100, 300, 500, 1000mA standard  
 ..... 100, 300, 500, 1000 mA Selektiv  
 Test currents .....  $I_{\Delta N}$  x0.5 / x1 / x2 / x5 (see table 1)  
 Test current type AC, ..... intermittent DC residual current  
 ..... DC  
 Phase position ..... 0° / 180°  
 Test current tolerance ..... 0...-10%  
 Measurement time ..... see table 3, when exceeding limits, immediate cut-off.  
 Measurement range ..... 2...1999ms  
 Resolution ..... 1ms  
 Tolerance .....  $\pm$  (2%+2Digit)  
 Limits ..... 25V / 50V, contact voltage limit UL to be pre-selected

**Measuring Trip Current (Ramp Funktion)**

Measurement ranges ..... 10, 30, 100, 300, 500, 1000mA Standard, see table 2  
 Test currents ..... 40% x  $I_{\Delta N}$ ...140% x  $I_{\Delta N}$ , bei AC  
 ..... 10% x  $I_{\Delta N}$ ...140% x  $I_{\Delta N}$ , bei pulsierendem Gleichfehlerstrom bzw. DC  
 Phase position ..... 0° / 180°  
 Measurement time ..... see table 3, when exceeding limits, immediate cut-off  
 Display ..... 10%  $I_{\Delta N}$ ...140%  $I_{\Delta N}$   
 Resolution ..... 10%  $I_{\Delta N}$   
 Tolerance .....  $\pm$  10%  $I_{\Delta N}$   
 Display ..... 0...1999ms

# Technical Data / 24 month Warranty

---

Resolution	.....	1ms
Tolerance	.....	$\pm (2\%+2\text{Digit})$
Display	.....	0...50 V
Resolution	.....	0,1 V bei $I_{\Delta N}$ 100, 300, 500, 1000mA
	.....	1V bei $I_{\Delta N}$ 10, 30mA
Tolerance	.....	-0%...+10% /+6 Digit
Limits	.....	25V / 50V, contact voltage limit UL to be pre-selected

## Auto function

Measurement ranges	.....	10, 30, 100, 300, 500, 1000mA idem
	.....	100, 300, 500, 1000 mA selective
Test currents	.....	0.5 x $I_{\Delta N}$ ,
	.....	1 x $I_{\Delta N}$ ,
	.....	2 x $I_{\Delta N}$ ,
	.....	5 x $I_{\Delta N}$ (not at $I_{\Delta N} = 500 / 1000$ mA standard or $\boxed{S}$ ),
	.....	automatic selection, also refer to table 1
Phase position	.....	0° / 180°, automatic selection
Measurement time	.....	see table 3, when exceeding limits, immediate cut-off
Display	.....	O.K. / bad ( POS / Err )
Limits	.....	25V / 50V, contact voltage limit UL to be pre-selected

## Mains Voltage Range

Measurement range	.....	3..300V AC
Tolerance	.....	+/- (3%+3 Digit)
Frequency range	.....	50/60Hz +/- 10%
Internal resistance	.....	approx. 300k $\Omega$
Oversupply protection	.....	400V AC/DC

## 24 month Warranty

UNITEST instruments are subject to strict quality control. However, should the instrument function improperly during daily use, you are protected by our 24 months warranty (valid only with invoice). We will repair free of charge any defects in workmanship or material, provided the instrument is returned unopened and untampered with, i.e. with undamaged warranty label. Any damage due to dropping or incorrect handling are not covered by the warranty. If the instrument shows failure following expiration of warranty, our service department can offer you a quick and economical repair.

Subject to technical changes without notice!

# Qualitätszertifikat • Certificate of Quality

## Certificat de Qualité • Certificado de calidad



Die BEHA-Gruppe bestätigt hiermit, dass das erworbene Produkt gemäß den festgelegten Beha-Prüfanweisungen während des Fertigungsprozesses kalibriert wurde. Alle innerhalb der Beha-Gruppe durchgeführten, qualitätsrelevanten Tätigkeiten und Prozesse werden permanent durch ein Qualitätsmanagement-System nach ISO 9000 überwacht.

Die BEHA-Gruppe bestätigt weiterhin, dass die während der Kalibrierung verwendeten Prüfeinrichtungen und Instrumente einer permanenten Prüfmittelüberwachung unterliegen. Die Prüfmittel und Instrumente werden in festgelegten Abständen mit Normalen kalibriert, deren Kalibrierung auf nationale und internationale Standards rückführbar ist.



The BEHA Group confirms herein that the unit you have purchased has been calibrated, during the manufacturing process, in compliance with the test procedures defined by BEHA. All BEHA procedures and quality controls are monitored on a permanent basis in compliance with the ISO 9000 Quality Management Standards.

In addition, the BEHA Group confirms that all test equipment and instruments used during the calibration process are subject to constant control. All test equipment and instruments used are calibrated at determined intervals, using reference equipment which has also been calibrated in compliance with (and traceable to) the calibration standards of national and international laboratories.



Le groupe BEHA déclare que l'appareil auquel ce document fait référence a été calibré au cours de sa fabrication selon les procédures de contrôle définies par BEHA. Toutes ces procédures et contrôles de qualité sont régis par le système de gestion ISO 9000.

Le groupe BEHA déclare par ailleurs que les équipements de contrôle et les instruments utilisés au cours du processus de calibrage sont eux-mêmes soumis à un contrôle technique permanent.

Ces mêmes équipements de contrôle sont calibrés régulièrement à l'aide d'appareils de référence calibrés selon les directives et normes en vigueur dans les laboratoires de recherche nationaux et internationaux.



El grupo BEHA declara que el producto adquirido ha sido calibrado durante la producción de acuerdo a las instrucciones de test BEHA. Todos los procesos y actividades llevados a cabo dentro del grupo BEHA en relación con la calidad del producto son supervisados permanentemente por el sistema ISO 9000 de control de calidad. Adicionalmente, el grupo BEHA constata que los equipos e instrumentos de prueba utilizados para la calibración también son sometidos a un permanente control. Estos equipos e instrumentos de prueba son a su vez calibrados en intervalos regulares valiéndose de equipos de referencia calibrados de acuerdo a directivas de laboratorios nacionales e internacionales.

**CH. BEHA GmbH**  
Elektrotechnik - Elektronik  
In den Engematten 14  
D-79286 Glottertal/Germany  
Tel. +49 (0) 76 84 / 80 09 - 0  
Fax +49 (0) 76 84 / 80 09 - 410  
e-mail: info@beha.de  
internet: <http://www.beha.com>



Reg. No. 3335  
Quality Management System  
ISO 9001

**IQ NET**

AENOR Spain AFAQ France AIB-Vincotte Inter Belgium APCER Portugal BSI United Kingdom CCSIQ Italy  
CQS Czech Republic DQS Germany DS Denmark ELOT Greece FCAV Brazil IRAM Argentina JQA Japan  
KEMA Netherlands KSA-QA Korea MSZT Hungary NCS Norway NSAI Ireland ÖQS Austria PCBC Poland PSB Singapore  
QAS Australia QMI Canada SFS Finland SII Israel JQA Japan SIQ Slovenia SIS-SAQ Sweden SQS Switzerland  
IQNet is represented in the USA by the following IQNet members: AFAQ, AIB-Vincotte Inter, BSI, DQS, KEMA, NSAI and QMI



I.S./ISO 9002/EN 29002  
Quality Management System



## **CH. BEHA GmbH** **Elektronik - Elektrotechnik**

In den Engematten 14  
79286 Glottertal/Germany  
Tel.: +49 (0) 76 84/80 09-0  
Fax: +49 (0) 76 84/80 09-410  
Techn. Hotline: +49 (0) 76 84/80 09-429  
internet: <http://www.beha.com>  
e-mail: [info@ beha.de](mailto:info@ beha.de)